



INCLUDES

• TENT CANOPY WITH GUY ROPES

- 2 X GUIDE PIPES
- 2 X UPRIGHT POLES
 - CROSS BAR
 - 4 X SAND PEGS
 - 4 X METAL PEGS
 - PEG BAG
 - CARRY BAG



Ensure that you read and understand this manual, improper assembly or failure to follow instructions may result in property damage and/or personal injury.

SETUP


1. Set out guide pipes

Click together the cross bar and place on the ground, then insert the guide pipes at each end.




2. Assemble the frame

- A. Screw together the upright poles and place in the guide pipes with spike at the top.
- *B. Place each end of the cross bar over the spikes.*




3. Set out the pegs

- A. Take three big steps back from the upright pole and one big step away from the pole to make an L shape.
- B. Hammer in the pegs. Use sand pegs at the beach and metal pegs at the park or in your backyard (hammer not included).



4. Arrange the canopy

- A. Lift the canopy over the cross bar.
- *B. Place the middle eyelet over the upright spike on one side.*
- *C.* Slide the canopy and attach the eyelet on the other upright pole. *i.* For an *L* shape set up, place the second eyelet over the upright
 - spike on each pole.



5. Check ropes

- *A. Check that the ropes are secured to the canopy.*
- *B. Pull out adjusters to create a loop and loop around the peg.*

6. Tension ropes

- A. Slide the black part of the rope up to tighten.
- B. Check all ropes and tighten as needed. Move pegs as needed to increase span.




PACK DOWN

1. Loosen ropes and remove pegs

2. Remove the canopy

- A. Remove the canopy from the upright pole and lift the canopy off the cross bar. Keep it folded in middle.
- *B.* Fold the canopy eyelet to eyelet, roll and wrap the ropes around the canopy.



3. Remove cross bar Remove the cross bar, unscrew the upright poles and remove the guide pipes.



4. *Pack and carry Pack away the canopy, pegs, poles and guide pipes into the storage bag.*

WARNINGS

- Always disassemble in windy conditions or when unattended.
- Product is designed as a shade shelter only.
- Keep away from open flames and heat sources.
- Ensure children are supervised at all times when the product is in use.

IMPORTANT INFO

- This product is designed as a shade shelter only. Reflections from the sand and water can still expose you to harmful UV rays. It is recommended that you wear sunscreen, hat and sunglasses when outside.
- Follow all instructions and tips when using this product.
- We are not responsible for the misuse, poor or incorrect set up of products that lead to damage or harm to any persons or property.
- For all warranty information, please visit www.palmclub.com.au/warranty

CARE INSTRUCTIONS

- Always follow the set up instructions for the product.
- *Keep the product dry and clean of any salt, sand or chlorine when storing to maintain and extend the product life.*
- Ensure the product is kept in the carry bag when not in use.
- If the product gets wet, dry with a soft towel and allow the fringing to drip dry in the shade before packing away.
- *Reduce unnecessary and excessive exposure to direct sunlight by packing the product away when not in use.*
- Maintain the functionality of the product by regularly cleaning and ensuring salt and sand is removed before storage.
- Avoid using chemicals on fabric clean with mild soapy water and dry thoroughly.



LET'S CONNECT



SCAN HERE

WWW.PALMCLUB.COM.AU

Designed by: Adventure Trading Australia Pty Ltd 71 Charles Ulm Place, Eagle Farm, QLD 4009 AUSTRALIA

Made in China

